

ul. Konstantynowska 79/81 95-200 Pabianice tel/fax 48 42 2270971 POLAND e-mail: fif@fif.com.pl

SCO-814

LIGHT DIMMERS

no "storage" of light intensity settings enabled



www.fif.com.pl

F&F products are covered by an 24 months warranty from date of purchase

PURPOSE

The dimmer is used for switching on and off incandescent and halogen lamps and offers the option of light intensity adjustment by means of any impulse switch (buzzer)

FUNCTIONING

Lighting is switching on by a current pulse sent after pressing an impulse switch (buzzer) connected to a relay. Another mpulse switches the lighting off. Pressing and holding the switch for more than 1 second allows the user to adjust light

switch of mide than is second allows the aspect of adjust light intensity (continuous loop adjustments in the following sequence: BRIGHTER DARKER BRIGHTER).

Light intensity may be controlled by means of numerous switches in a parallel connection, distributed in several locations with in a room.

ASSEMBLY

- 1. Take OFF the power.
- Put on the rail in the switchgear box.
 Connect it with wiring diagram.

TECHNICAL DATA

supply 230VAC current load <4,5A maximum power of light bulbs connected 1000W current pulse duration <1sec 0,3W power consumption working temperature -25÷50°C connection screw terminals 2,5mm2 3 modules (52,5mm) on the rail TH-35 dimensions fixing WTA 5×206,3A overcurrent protection

ATTENTION!


SCO-814 is compatible with bell pushes equipped with fluorescent lamps.

ATTENTION!


There may be working irregularities with certain electronic feeders (e.g. flickering may appear). Therefore, some feeder types require light bulbs or halogens of total power up to 50% of the feeder's nominal.

Tests are recommended before final assembly and commission.

WIRING DIAGRAM



CHANGE OF FUSE ELEMENT WTA 5×20



A090617